

---

Posted by [bltll](#) on Fri, 22 Feb 2008 11:23:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

2.

BAD-HN ~ # lspci -vv | grep Ethe

04:00.0 Ethernet controller: Intel Corporation PRO/1000 EB Network Connection with I/O Acceleration (rev 01)

04:00.1 Ethernet controller: Intel Corporation PRO/1000 EB Network Connection with I/O Acceleration (rev 01)

BAD-HN ~ # dmesg | grep eth

e1000: eth0: e1000\_probe: Intel(R) PRO/1000 Network Connection

e1000: eth0: e1000\_watchdog: NIC Link is Up 100 Mbps Full Duplex

e1000: eth0: e1000\_watchdog: 10/100 speed: disabling TSO