
Subject: Re: development kernel can not boot
Posted by [attackghost](#) on Fri, 23 Jun 2006 01:54:09 GMT
[View Forum Message](#) <> [Reply to Message](#)

Command "lcpci -n" not found. Is it "lspci -n"?
Thanks.

```
[root@node8 ~]# lspci
00:00.0 Host bridge: ServerWorks GCNB-LE Host Bridge (rev 32)
00:00.1 Host bridge: ServerWorks GCNB-LE Host Bridge
00:08.0 VGA compatible controller: ATI Technologies Inc Rage XL (rev 27)
00:0f.0 ISA bridge: ServerWorks CSB6 South Bridge (rev a0)
00:0f.1 IDE interface: ServerWorks CSB6 RAID/IDE Controller (rev a0)
00:0f.2 USB Controller: ServerWorks CSB6 OHCI USB Controller (rev 05)
00:0f.3 Host bridge: ServerWorks GCLE-2 Host Bridge
00:10.0 Host bridge: ServerWorks CIOB-X2 PCI-X I/O Bridge (rev 05)
00:10.2 Host bridge: ServerWorks CIOB-X2 PCI-X I/O Bridge (rev 05)
01:02.0 PCI bridge: Mellanox Technologies MT23108 PCI Bridge (rev a1)
02:00.0 InfiniBand: Mellanox Technologies MT23108 InfiniHost (rev a1)
03:04.0 SCSI storage controller: LSI Logic / Symbios Logic 53c1030 PCI-X Fusion-MPT Dual
Ultra320 SCSI (rev 07)
03:05.0 Ethernet controller: Intel Corp. 82540EM Gigabit Ethernet Controller (rev 02)
[root@node8 ~]# lcpci -n
-bash: lcpci: command not found
[root@node8 ~]# lspci -n
00:00.0 Class 0600: 1166:0017 (rev 32)
00:00.1 Class 0600: 1166:0017
00:08.0 Class 0300: 1002:4752 (rev 27)
00:0f.0 Class 0601: 1166:0203 (rev a0)
00:0f.1 Class 0101: 1166:0213 (rev a0)
00:0f.2 Class 0c03: 1166:0221 (rev 05)
00:0f.3 Class 0600: 1166:0227
00:10.0 Class 0600: 1166:0101 (rev 05)
00:10.2 Class 0600: 1166:0101 (rev 05)
01:02.0 Class 0604: 15b3:5a46 (rev a1)
02:00.0 Class 0c06: 15b3:5a44 (rev a1)
03:04.0 Class 0100: 1000:0030 (rev 07)
03:05.0 Class 0200: 8086:100e (rev 02)
```
