

---

Subject: 2.6.18-028stab053 doesn't find my NIC.

Posted by [januszzz](#) on Tue, 03 Jun 2008 12:51:57 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi,

I compiled kernel from stable sources (Gentoo ebuild: openvz-sources-2.6.18.028.053-r2). The problem is after reboot I don't have my NIC, which is:

02:00.0 Ethernet controller: Broadcom Corporation NetXtreme BCM5722 Gigabit Ethernet PCI Express

Subsystem: Dell Unknown device 0225

Flags: bus master, fast devsel, latency 0, IRQ 10

Memory at d0200000 (64-bit, non-prefetchable) [size=64K]

Capabilities: [48] Power Management version 3

Capabilities: [50] Vital Product Data <?>

Capabilities: [58] Vendor Specific Information <?>

Capabilities: [e8] Message Signalled Interrupts: Mask- 64bit+ Queue=0/0 Enable-

Capabilities: [d0] Express Endpoint, MSI 00

Capabilities: [100] Advanced Error Reporting <?>

Capabilities: [13c] Virtual Channel <?>

Capabilities: [160] Device Serial Number 90-4a-2a-fe-ff-09-1d-00

Capabilities: [16c] Power Budgeting <?>

I'm not exactly sure which module should I use; I tried tg3, bnx2, and even e1000 - nothing works. Ifconfig -a displays only realtek (true, I had it put inside, its remote machine), sit0, lo and venet0.

The machine is:

Manufacturer: Dell Inc.

Product Name: PowerEdge T105

I wasn't sure on which module the NIC was running (I remotely installed Gentoo with 2.6.24) but I was running there it fine.

I have to stay on this kernel now, as the server is completely unattended now.

Regards,

Janusz.

---

---

Subject: Re: 2.6.18-028stab053 doesn't find my NIC.

Posted by [adobriyan](#) on Tue, 03 Jun 2008 14:34:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

That's tg3 (CONFIG\_TIGON3).

Post lspci -nn output.

---

---

Subject: Re: 2.6.18-028stab053 doesn't find my NIC.  
Posted by [januszzz](#) on Tue, 03 Jun 2008 19:43:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Ok, I'm sending it all:

00:00.0 Memory controller [0580]: nVidia Corporation CK804 Memory Controller [10de:005e] (rev a4)  
00:01.0 ISA bridge [0601]: nVidia Corporation CK804 ISA Bridge [10de:0051] (rev f1)  
00:01.1 SMBus [0c05]: nVidia Corporation CK804 SMBus [10de:0052] (rev a2)  
00:02.0 USB Controller [0c03]: nVidia Corporation CK804 USB Controller [10de:005a] (rev a2)  
00:02.1 USB Controller [0c03]: nVidia Corporation CK804 USB Controller [10de:005b] (rev a4)  
00:07.0 IDE interface [0101]: nVidia Corporation CK804 Serial ATA Controller [10de:0054] (rev f3)  
00:08.0 IDE interface [0101]: nVidia Corporation CK804 Serial ATA Controller [10de:0055] (rev f3)  
00:09.0 PCI bridge [0604]: nVidia Corporation CK804 PCI Bridge [10de:005c] (rev f2)  
00:0b.0 PCI bridge [0604]: nVidia Corporation CK804 PCIE Bridge [10de:005d] (rev f3)  
00:0c.0 PCI bridge [0604]: nVidia Corporation CK804 PCIE Bridge [10de:005d] (rev f3)  
00:0d.0 PCI bridge [0604]: nVidia Corporation CK804 PCIE Bridge [10de:005d] (rev f3)  
00:0e.0 PCI bridge [0604]: nVidia Corporation CK804 PCIE Bridge [10de:005d] (rev a3)  
00:18.0 Host bridge [0600]: Advanced Micro Devices [AMD] K8 [Athlon64/Opteron]  
HyperTransport Technology Configuration [1022:1100]  
00:18.1 Host bridge [0600]: Advanced Micro Devices [AMD] K8 [Athlon64/Opteron] Address Map  
[1022:1101]  
00:18.2 Host bridge [0600]: Advanced Micro Devices [AMD] K8 [Athlon64/Opteron] DRAM  
Controller [1022:1102]  
00:18.3 Host bridge [0600]: Advanced Micro Devices [AMD] K8 [Athlon64/Opteron] Miscellaneous  
Control [1022:1103]  
01:07.0 Ethernet controller [0200]: Realtek Semiconductor Co., Ltd. RTL-8139/8139C/8139C+  
[10ec:8139] (rev 10)  
01:08.0 VGA compatible controller [0300]: ATI Technologies Inc ES1000 [1002:515e] (rev 02)  
02:00.0 Ethernet controller [0200]: Broadcom Corporation NetXtreme BCM5722 Gigabit Ethernet  
PCI Express [14e4:165a]  
05:00.0 SCSI storage controller [0100]: LSI Logic / Symbios Logic SAS1068E PCI-Express  
Fusion-MPT SAS [1000:0058] (rev 08)

```
optek ~ # lsmod | grep tg3
tg3          104068  0
optek ~ # ifconfig -a
eth0      Link encap:Ethernet HWaddr 00:0A:CD:14:FF:24
          inet addr:192.168.0.68 Bcast:192.168.0.255 Mask:255.255.255.0
          inet6 addr: fe80::20a:cdff:fe14:ff24/64 Scope:Link
            UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
            RX packets:1016054 errors:0 dropped:0 overruns:0 frame:0
            TX packets:89940 errors:0 dropped:0 overruns:0 carrier:0
            collisions:0 txqueuelen:1000
            RX bytes:144908123 (138.1 Mb) TX bytes:14403934 (13.7 Mb)
            Interrupt:19 Base address:0x2000

lo      Link encap:Local Loopback
```

```
inet addr:127.0.0.1 Mask:255.0.0.0
inet6 addr: ::1/128 Scope:Host
      UP LOOPBACK RUNNING MTU:16436 Metric:1
      RX packets:0 errors:0 dropped:0 overruns:0 frame:0
      TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
      collisions:0 txqueuelen:0
      RX bytes:0 (0.0 b) TX bytes:0 (0.0 b)

sit0    Link encap:IPv6-in-IPv4
        NOARP MTU:1480 Metric:1
        RX packets:0 errors:0 dropped:0 overruns:0 frame:0
        TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
        collisions:0 txqueuelen:0
        RX bytes:0 (0.0 b) TX bytes:0 (0.0 b)

venet0   Link encap:UNSPEC HWaddr 00-00-00-00-00-00-00-00-00-00-00-00-00-00-00-00
         UP BROADCAST POINTOPOINT RUNNING NOARP MTU:1500 Metric:1
         RX packets:23 errors:0 dropped:0 overruns:0 frame:0
         TX packets:5 errors:0 dropped:0 overruns:0 carrier:0
         collisions:0 txqueuelen:0
         RX bytes:1688 (1.6 Kb) TX bytes:420 (420.0 b)
```

eth0 is immortal realtek 8139 as you can see.

---

---

Subject: Re: 2.6.18-028stab053 doesn't find my NIC.  
Posted by [adobriyan](#) on Wed, 04 Jun 2008 08:37:19 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

> 02:00.0 Ethernet controller [0200]: Broadcom Corporation NetXtreme BCM5722 Gigabit Ethernet PCI Express [14e4:165a]

0x165a support was added after 2.6.18, so try attached patch and reload with new module.

> eth0 is immortal realtek 8139

In nuclear war realteks will survive. ;-)

#### File Attachments

1) [tg3.patch](#), downloaded 350 times

---

---

Subject: Re: 2.6.18-028stab053 doesn't find my NIC.  
Posted by [januszzz](#) on Wed, 04 Jun 2008 19:57:15 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Ok, done, interface is up. Honestly, one more question, maybe more distro specific:

how can I be sure that after reboot those cards are not switched back? now there is no problem, but if the power outage occurs and cards are switched, I'm cut off. From server and money too.

ANyway this is <SOLVED>.

---

---

**Subject: Re: 2.6.18-028stab053 doesn't find my NIC.**

Posted by [adobriyan](#) on Thu, 05 Jun 2008 09:22:44 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

> how can I be sure that after reboot those cards are not switched back?

Well, on the kernel side ordering should stay the same,  
assuming you

- \* aren't physically moving NICs in PCI slots, and
- \* don't flip between 2.4 and 2.6 kernels (those two enumerate  
PCI devices in different order, use pci=bsort to get 2.4  
behaviour)
- \* and don't change =y=/m settings of NIC modules

Userspace (read: udev) on modern distros will try to rename  
NICs back looking at their MACs. You can look at  
`/etc/udev/rules.d/70-persistent-net.rules` (or how it's called).

---