

---

Subject: Re: Ploop - anyone using in production yet?

Posted by [kir](#) on Thu, 26 Apr 2012 16:44:30 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Rene,

For simfs, diskspace parameter is basically a quota limit for given CT. For ploop, diskspace becomes the size of ploop device, and thus it can't be set arbitrarily high.

So, before trying to convert, set diskspace to some sensible value, for example

```
vzctl set 5000 --diskspace 10G --save
```

or smth. Then convert.

I have modified vzctl to check for too high value of diskspace and emit an error if it is the case.

---